

---

## Load Connection

The preferred method of coupling a load to the shaft is by a setscrew or collet fixing. AML do not recommend users modify shafts.

---