

# Wrong driver selected error

If you receive a “**Wrong driver selected**” error when updating your device, follow the steps below.



Do not close the error message box until you have completed these steps. Once the box is closed, the device may exit bootloader mode which will prevent you from carrying out the remaining steps.

1. Go to Device Manager and find the device. It will be listed as **STM Device in DFU Mode**.


Device Manager
File
Action
View
Help
AML-1
Audio inputs and outputs
Biometric devices
Bluetooth
Cameras
Computer
Disk drives
Display adaptors
DVD/CD-ROM drives
Firmware
Human Interface Devices
IDE ATA/ATAPI controllers
Imaging devices
Keyboards
Mice and other pointing devices
Monitors
Network adapters
Ports (COM & LPT)
Print queues
Printers
Processors
Security devices
Software components
Software devices
Sound, video and game controllers
Storage controllers
System devices
Universal Serial Bus controllers
ASMedia USB 3.1 eXtensible Host Controller - 1.10 (Microsoft)
Corsair USBXp Driver
Generic USB Hub
Generic USB Hub
Intel(R) USB 3.1 eXtensible Host Controller - 1.10 (Microsoft)
J-Link driver
LIGHTSPEED Receiver
STM Device in DFU Mode
USB Composite Device
USB Composite Device
USB Root Hub (USB 3.0)
USB Root Hub (USB 3.0)