
Troubleshooting

If the motor rotates at the wrong speed, frequently changes direction, or has low torque this is probably due to one of the phase connections being open circuit.

If the drive indicates that the motor temperature exceeds 200 °C when the motor is not hot, then a connection to the thermocouple is open circuit
